


LED Flood Light Data Sheet

JMG240W**K 3000-4000K Range

Patented Technology Thermal Resonance Heat Transfer LED 0 Housing Material Aluminum Power Unit/Transformer Power supply unit	Cooling
	Journa
Driver/Power Unit/Transformer Power supply unit	
= ::: -::: -:: -:: -:: -:: -:: -:: -::	
Electrical Protection Safety class I	
CQC Certification CQC	
SAA Certification SAA	
IP Rating IP66/67	
IK Rating IK10	
Mount Post Top	
Operating Ambient Temperature Range -40 to +55 °C	
Operating Ambient Humidity Range 0-95%	
Light Source COB	
Electrical Data	
Power 240W	
Input Voltage 220-240 V	
Input Frequency 50 to 60 Hz	
Power Factor (Nom) 0.97	
Power Efficiency ≥ 95%	
Lifespan L70B50 100,000	
Warranty 5 - 10 years	
Optical Data	
Luminaire Efficacy (Lm/W) 3000K 153	
4000K 175	
Luminous Flux (Lm) 3000K 36.720	
3000K 36,720 4000K 42,000	
CRI (Ra) 70	
Annual Light Decay ≤ 2%	
Distribution Type Flood Lighting	
Physical Data	
Product Dimensions (Mm) 670(L) x 420(W) x 240(H)	
Maximum Wind Area (M2) 0.08	
Product Net Weight (Kg) 10	
Packaging Data	
Packaging Dimensions (Mm) 690(L) x 440(W) x 275(H)	





Diagrams



Installation method

Luminaires should be placed at a 15 degree inclination angle with the horizontal plane to avoid uneven distribution of light. As shown in the figure below. The product light source has a certain tilt angle with the ground, and the heat dissipation body cannot be placed vertically or at an elevation angle of the product.







Safety Instructions

- 1. Warning! All power must be disconnected at power source before any installation and service procedure is performed. Maintenance of lamps and lanterns must be performed by professional technician, non-professional do not remove lamps and lanterns;
- 2. This appliance is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as drapes and other furnishings, away from appliance.
- 3. Extreme caution is necessary when any appliance is used by or near children and whenever the appliance is left unattended.
- 4. Always disconnect appliance before cleaning, adjusting or maintaining this machine.
- 5. To prevent a possible fire, it is recommended that the unit is placed on a non-combustible surface.
- 6. This appliance has electrical parts. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.